

## Spinning Top

- 1) Put blue plastic plug in top of aluminium pole.
- 2) Insert stainless bolt through a small washer, then the larger washer and then smaller washer.
- 3) Thread the bolt into the blue plastic plug enough so the washers are not squeezed together and can easily rotate but are not floppy.
- 4) Attach key ring on the end of the flying line through the small hole on the edge of the washer.

Take original ring and line off of the top of the aluminium pole as well as the two pieces of white tape. If you do not the flying line will wrap.

Angle pole at approximately 35 degrees. If there is a constant direction with the wind, angle the top of the pole pointing in the same direction the wind is blowing. For instance, if the wind is blowing West to East, angle the top of the pole towards the East.